

INSTALLATION & MAINTENANCE MANUAL RCTRGB











GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following product: RCTRGB

SAFETY

- Installation of this product should only be carried out by a qualified electrician or competent person to the current Building and IEE Wiring Regulations (BS7671)
- Please isolate mains prior to installation/maintenance
- Check the total load on the circuit (including when this luminaire is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress of Protection) rating of this luminaire when deciding the location for installation
- This product is Class II double insulated
- This product is IP44 rated
- This product requires 2 people to install

INSTALLATION

- Provide power to the point of installation. Suitable IP rated junction boxes should be used where required
- Using the mounting plate as a template, drill appropriate sized holes for the fixings ensuring not to infringe with any gas/water pipes or electrical cables
- Secure mounting plate to the surface using appropriate fixings
- Remove the 2 screws securing the gear tray cover (see Fig 1)






Fig 1

• Ensuring correct polarity is observed - connect Live (brown), Neutral (blue) into the terminal block (see Fig 2)



- Fig 2
- Refit the gear tray cover onto the fitting and fasten the 2 screws
- Carefully position fitting onto the mounting plate
- Switch on the power supply and check for correct operation

REMOTE AND SETTINGS



WARNING

This product must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed.

GENERAL

The product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

WARRANTY

This product has a warranty of 3 years from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations, improper use, or removal of the batch codes will invalidate the warranty. If this product should fail within its warranty period it should be returned to the place of purchase for a replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

